


# AMBIENT TEMPERATURE SENSOR


## COMPONENTS




AC

## REMOVAL

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE AMBIENT TEMPERATURE SENSOR**
  - (a) Disconnect the connector.
  - (b) Disengage the clamp and remove the ambient temperature sensor.



AC



## INSPECTION

1. **INSPECT AMBIENT TEMPERATURE SENSOR**
  - (a) Measure the resistance.

**Standard resistance**

Tester Connection	Condition	Specified Condition
1 - 2	10°C (50°F)	3.00 to 3.73 kΩ
1 - 2	15°C (59°F)	2.45 to 2.88 kΩ
1 - 2	20°C (68°F)	1.95 to 2.30 kΩ
1 - 2	25°C (77°F)	1.60 to 1.80 kΩ
1 - 2	30°C (86°F)	1.28 to 1.47 kΩ
1 - 2	35°C (95°F)	1.00 to 1.22 kΩ
1 - 2	40°C (104°F)	0.80 to 1.00 kΩ
1 - 2	45°C (113°F)	0.65 to 0.85 kΩ
1 - 2	50°C (122°F)	0.50 to 0.70 kΩ
1 - 2	55°C (131°F)	0.44 to 0.60 kΩ
1 - 2	60°C (140°F)	0.36 to 0.50 kΩ

**NOTICE:**

- Touching the sensor even slightly may change the resistance value. Hold the connector of the sensor.
- When measuring the resistance, the temperature of the sensor and the ambient temperature sensor must be the same.

**HINT:**

As the temperature increases, the resistance decreases (see the graph).