

DTC

B1783


Rear Occupant Classification Sensor RH Circuit Malfunction**DESCRIPTION**

The rear occupant classification sensor RH circuit consists of the occupant classification ECU and the rear occupant classification sensor RH.

DTC B1783 is recorded when a malfunction is detected in the rear occupant classification sensor RH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1783	<ul style="list-style-type: none"> Occupant classification ECU detects line short circuit signal, open circuit signal, short circuit to ground signal or short circuit to B+ signal in the rear occupant classification sensor RH circuit for 2 seconds Rear occupant classification sensor RH malfunction Occupant classification ECU malfunction 	<ul style="list-style-type: none"> No. 1 seat wire RH Front seat assembly RH (Rear occupant classification sensor RH) Occupant classification ECU

RS

WIRING DIAGRAM

INSPECTION PROCEDURE

HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front passenger seat installation bolts to see the under surface of the seat cushion.
- In the above case, hold the seat so that it does not tip over. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat up only for as long as necessary.

1**CHECK DTC**

- Turn the ignition switch to the on position.
- Clear the DTCs stored in the memory (See page [RS-254](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- Turn the ignition switch to the lock position.
- Turn the ignition switch to the on position.
- Check the DTCs (See page [RS-254](#)).

OK:

DTC B1783 is not output.

HINT:

Codes other than DTC B1783 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

2**CHECK CONNECTION OF CONNECTORS**

- Turn the ignition switch to the lock position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Check that the connectors are properly connected to the occupant classification ECU and the rear occupant classification sensor RH.

OK:

The connectors are properly connected.


NG

CONNECT CONNECTORS

OK

RS

3 CHECK NO.1 SEAT WIRE (TO B+)



- (a) Disconnect the connectors from the occupant classification ECU and the rear occupant classification sensor RH.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the on position.
- (d) Measure the voltage.

Standard voltage


Tester connection	Condition	Specified condition
Q5-4 (SGD4) - Body ground	Ignition switch on	Below 1 V
Q5-6 (SVC4) - Body ground	Ignition switch on	Below 1 V
Q5-10 (SIG4) - Body ground	Ignition switch on	Below 1 V

NG

REPAIR OR REPLACE NO.1 SEAT WIRE

OK

4 CHECK NO.1 SEAT WIRE (FOR OPEN)



- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Using a service wire, connect Q6-1 (SVC4) and Q6-3 (SGD4), and connect Q6-2 (SIG4) and Q6-3 (SGD4) of connector C.

NOTICE:

Do not forcibly insert a service wire into the terminals of the connector when connecting.

- (d) Measure the resistance.

Standard resistance


Tester connection	Condition	Specified condition
Q5-6 (SVC4) - Q5-4 (SGD4)	Always	Below 1 Ω
Q5-10 (SIG4) - Q5-4 (SGD4)	Always	Below 1 Ω

NG

REPAIR OR REPLACE NO.1 SEAT WIRE

OK

5 CHECK NO.1 SEAT WIRE (FOR SHORT)



- (a) Disconnect the service wire from connector C.
- (b) Measure the resistance.

Standard resistance


Tester connection	Condition	Specified condition
Q5-6 (SVC4) - Q5-4 (SGD4)	Always	1 MΩ or higher
Q5-10 (SIG4) - Q5-4 (SGD4)	Always	1 MΩ or higher
Q5-6 (SVC4) - Q5-10 (SIG4)	Always	1 MΩ or higher

NG REPAIR OR REPLACE NO.1 SEAT WIRE

OK

RS

6 CHECK NO.1 SEAT WIRE (TO GROUND)



- (a) Measure the resistance.
- Standard resistance**

Tester connection	Condition	Specified condition
Q5-4 (SGD4) - Body ground	Always	1 MΩ or higher
Q5-6 (SVC4) - Body ground	Always	1 MΩ or higher
Q5-10 (SIG4) - Body ground	Always	1 MΩ or higher

NG REPAIR OR REPLACE NO.1 SEAT WIRE

OK

7 CHECK DTC

- (a) Connect the connectors to the occupant classification ECU and the rear occupant classification sensor RH.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the on position.
- (d) Clear the DTCs stored in the memory (See page [RS-254](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (e) Turn the ignition switch to the lock position.
- (f) Turn the ignition switch to the on position.
- (g) Check the DTCs (See page [RS-254](#)).

OK:

DTC B1783 is not output.

HINT:

Codes other than DTC B1783 may be output at this time, but they are not related to this check.

OK**USE SIMULATION METHOD TO CHECK****NG****8 REPLACE OCCUPANT CLASSIFICATION ECU**

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (See page [RS-412](#)).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

NEXT**9 PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the on position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-246](#)).

OK:

COMPLETED is displayed.

NG**Go to step 12****OK**

10 PERFORM SENSITIVITY CHECK

- (a) Using the intelligent tester, perform the sensitivity check (See page [RS-246](#)).
- (1) Confirm that nothing is placed on the passenger seat.
 - (2) Confirm that the beginning sensor reading is within the standard range.
Standard range:
-3.2 to 3.2 kg (-7 to 7 lb)
 - (3) Place a 30 kg (66.14 lb) weight (e.g. a lead mass) onto the front passenger seat.
 - (4) Confirm that the sensitivity is within the standard range.
Standard range:
27 to 33 kg (59.52 to 72.75 lb)
- HINT:
When performing the sensitivity check, use a solid metal weight (the check result may not be accurate if a liquid weight is used).

NG

Go to step 12

OK

11 CHECK DTC

- (a) Connect the negative (-) terminal cable to the battery.
 - (b) Turn the ignition switch to the on position.
 - (c) Clear the DTCs stored in the memory (See page [RS-254](#)).
HINT:
First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.
 - (d) Turn the ignition switch to the lock position.
 - (e) Turn the ignition switch to the on position.
 - (f) Check the DTCs (See page [RS-254](#)).
- OK:**
DTC B1783 is not output.
- HINT:
Codes other than DTC B1783 may be output at this time, but they are not related to this check.

OK

END

NG

12 REPLACE FRONT SEAT ASSEMBLY RH

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the front seat assembly RH (See page [SE-5](#)).

RS

NEXT

13 | **PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the on position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-246](#)).

OK:

COMPLETED is displayed.

NEXT

14 | **PERFORM SENSITIVITY CHECK**

- (a) Using the intelligent tester, perform the sensitivity check (See page [RS-246](#)).
 - (1) Confirm that nothing is placed on the passenger seat.
 - (2) Confirm that the beginning sensor reading is within the standard range.
Standard range:
-3.2 to 3.2 kg (-7 to 7 lb)
 - (3) Place a 30 kg (66.14 lb) weight (e.g. a lead mass) onto the front passenger seat.
 - (4) Confirm that the sensitivity is within the standard range.

Standard range:

27 to 33 kg (59.52 to 72.75 lb)

HINT:

When performing the sensitivity check, use a solid metal weight (the check result may not be accurate if a liquid weight is used).

NEXT

END