

DTC	B1793	Occupant Classification Sensor Power Supply Circuit Malfunction
------------	--------------	--


DESCRIPTION

The occupant classification sensor power supply circuit consists of the occupant classification ECU and the occupant classification sensors.

DTC B1793 is recorded when a malfunction is detected in the occupant classification sensor power supply circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1793	<ul style="list-style-type: none">• Occupant classification ECU detects line short circuit signal, open circuit signal, short circuit to ground signal or short circuit to B+ signal in the occupant classification sensor power supply circuit for 2 seconds• Occupant classification ECU malfunction	<ul style="list-style-type: none">• No. 1 seat wire• Front seat assembly RH (Occupant classification sensors)• Occupant classification ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front passenger seat installation bolts to see the under surface of the seat cushion.
- In the above case, hold the seat so that it does not tip over. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat up only for as long as necessary.

1

CHECK DTC

- Turn the ignition switch to the on position.
- Clear the DTCs stored in the memory (See page [RS-254](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (c) Turn the ignition switch to the lock position.
- (d) Turn the ignition switch to the on position.
- (e) Check the DTCs (See page RS-254).

OK:

DTC B1793 is not output.

HINT:

Codes other than DTC B1793 may be output at this time, but they are not related to this check.

OK USE SIMULATION METHOD TO CHECK

NG

2 CHECK CONNECTION OF CONNECTORS

RS

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the occupant classification ECU and the occupant classification sensors.


OK:

The connectors are properly connected.

NG CONNECT CONNECTORS

OK

3 CHECK NO.1 SEAT WIRE (TO B+)




- (a) Disconnect the connectors from the occupant classification ECU and the 4 occupant classification sensors.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the on position.
- (d) Measure the voltage.

Standard voltage

Tester connection	Condition	Specified condition
Q5-11 (SVC1) - Body ground	Ignition switch on	Below 1 V
Q5-12 (SVC2) - Body ground	Ignition switch on	Below 1 V
Q5-5 (SVC3) - Body ground	Ignition switch on	Below 1 V
Q5-6 (SVC4) - Body ground	Ignition switch on	Below 1 V

NG REPAIR OR REPLACE NO.1 SEAT WIRE

OK

4 CHECK NO.1 SEAT WIRE (TO GROUND)

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Measure the resistance.

Standard resistance

Tester connection	Condition	Specified condition
Q5-11 (SVC1) - Body ground	Always	1 M Ω or higher
Q5-12 (SVC2) - Body ground	Always	1 M Ω or higher
Q5-5 (SVC3) - Body ground	Always	1 M Ω or higher
Q5-6 (SVC4) - Body ground	Always	1 M Ω or higher


NG

REPAIR OR REPLACE NO.1 SEAT WIRE

OK

RS

5 CHECK NO.1 SEAT WIRE (FOR OPEN)



(a) Measure the resistance.

Standard resistance


Tester connection	Condition	Specified condition
Q5-11 (SVC1) - Q1-1 (SVC1)	Always	Below 1 Ω
Q5-12 (SVC2) - Q7-1 (SVC2)	Always	Below 1 Ω
Q5-5 (SVC3) - Q2-1 (SVC3)	Always	Below 1 Ω
Q5-6 (SVC4) - Q6-1 (SVC4)	Always	Below 1 Ω

NG REPAIR OR REPLACE NO.1 SEAT WIRE

OK

RS

6 CHECK NO.1 SEAT WIRE (FOR SHORT)



(a) Measure the resistance.

Standard resistance

Tester connection	Condition	Specified condition
Q5-5 (SVC3) - Q5-6 (SVC4)	Always	1 MΩ or higher
Q5-6 (SVC4) - Q5-11 (SVC1)	Always	1 MΩ or higher
Q5-11 (SVC1) - Q5-12 (SVC2)	Always	1 MΩ or higher
Q5-12 (SVC2) - Q5-5 (SVC3)	Always	1 MΩ or higher
Q5-12 (SVC2) - Q5-6 (SVC4)	Always	1 MΩ or higher

Tester connection	Condition	Specified condition
Q5-11 (SVC1) - Q5-5 (SVC3)	Always	1 M Ω or higher

NG

REPAIR OR REPLACE NO.1 SEAT WIRE

OK

7**CHECK DTC**

- (a) Connect the connectors to the occupant classification ECU and the 4 occupant classification sensors.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the on position.
- (d) Clear the DTCs stored in the memory (See page [RS-254](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (e) Turn the ignition switch to the lock position.
- (f) Turn the ignition switch to the on position.
- (g) Check the DTCs (See page [RS-254](#)).

OK:**DTC B1793 is not output.**

HINT:

Codes other than DTC B1793 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

8**REPLACE OCCUPANT CLASSIFICATION ECU**

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (See page [RS-412](#)).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

NEXT

9**PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the on position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-246](#)).

OK:
COMPLETED is displayed.

NG

Go to step 12

OK

10 PERFORM SENSITIVITY CHECK

(a) Using the intelligent tester, perform the sensitivity check (See page [RS-246](#)).

- (1) Confirm that nothing is placed on the passenger seat.
- (2) Confirm that the beginning sensor reading is within the standard range.

Standard range:

-3.2 to 3.2 kg (-7 to 7 lb)

(3) Place a 30 kg (66.14 lb) weight (e.g. a lead mass) onto the front passenger seat.

(4) Confirm that the sensitivity is within the standard range.

Standard range:

27 to 33 kg (59.52 to 72.75 lb)

HINT:

When performing the sensitivity check, use a solid metal weight (the check result may not be accurate if a liquid weight is used).

NG

Go to step 12

OK

11 CHECK DTC

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Turn the ignition switch to the on position.
- (c) Clear the DTCs stored in the memory (See page [RS-254](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (d) Turn the ignition switch to the lock position.
- (e) Turn the ignition switch to the on position.
- (f) Check the DTCs (See page [RS-254](#)).

OK:

DTC B1793 is not output.

HINT:

Codes other than DTC B1793 may be output at this time, but they are related to this check.

OK

END

NG

RS

12 REPLACE FRONT SEAT ASSEMBLY RH

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the front seat assembly RH (See page [SE-5](#)).

NEXT**13 PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the on position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-246](#)).

OK:**COMPLETED is displayed.****NEXT****14 PERFORM SENSITIVITY CHECK**

- (a) Using the intelligent tester, perform the sensitivity check (See page [RS-246](#)).
 - (1) Confirm that nothing is placed on the passenger seat.
 - (2) Confirm that the beginning sensor reading is within the standard range.
- (3) Place a 30 kg (66.14 lb) weight (e.g. a lead mass) onto the front passenger seat.
- (4) Confirm that the sensitivity is within the standard range.

Standard range:**-3.2 to 3.2 kg (-7 to 7 lb)****HINT:**

When performing the sensitivity check, use a solid metal weight (the check result may not be accurate if a liquid weight is used).

NEXT**END**