


## Washer Motor Circuit

### DESCRIPTION

The main body ECU controls the rear washer motor.

### WIRING DIAGRAM



WW

### INSPECTION PROCEDURE

#### 1 INSPECT FUSE (RR WSH)

- (a) Remove the RR WSH fuse from the main body ECU.
- (b) Measure the resistance.

**OK:**

**Below 1 Ω**


- (c) Reinstall the RR WSH fuse.

**NG**

**REPLACE FUSE**

**OK**

#### 2 INSPECT REAR WASHER MOTOR ASSEMBLY



- (a) Disconnect the rear washer motor assembly connector.
- (b) Connect the battery's positive (+) lead to terminal 1 and the negative (-) lead to terminal 2.
- (c) Check that the rear washer motor operates.

**OK:**

**Rear washer motor operates.**

- (d) Reconnect the rear washer motor assembly connector.

**NG**


**REPLACE REAR WASHER MOTOR ASSEMBLY**

**OK**

**3 CHECK HARNESS AND CONNECTOR (REAR WASHER MOTOR - MAIN BODY ECU)**


**Wire Harness Side:**

Rear Washer Motor Assembly Connector



Front View

Main Body ECU Connector



Front View

B136066E01

- (a) Disconnect the rear washer motor assembly connector.
- (b) Disconnect the 1B main body ECU connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
1B-1 (WMTR) - Rear washer motor assembly connector 1	Below 1 Ω
1B-1 (WMTR) - Body ground	10 kΩ or higher
Rear washer motor assembly connector 1 - Body ground	Below 1 Ω

- (d) Reconnect the rear washer motor assembly connector.
- (e) Reconnect the main body ECU connector.

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**REPLACE MAIN BODY ECU**