



Warrior, Inc.  
11100 SW Industrial Way  
Tualatin, Oregon 97062  
(503) 691-8915 Main  
(503) 692-0364 Fax  
(888) 220-6861 Toll Free  
[techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com)

---

**SUBJECT:** P/N 1519 – Tube Door Mirror Bracket Installation Instructions

**NOTE:** These mirror brackets will fit all JK Wrangler Front Tube Doors as well as Front Tube Doors for all Cherokee XJ Models. This kit includes mirror to be used in the installation.

**Installation:**

1. These brackets mount to the outside of the triangular gusset located on the top hinge pin of your tube doors. They should be located so that the tube on the mirror bracket sits outside of the door when installed on the vehicle.
2. Start by aligning the brackets on the gusset of the tube door and marking the locations to be drilled. A silver or white colored pencil draws very well on the black powder coat. You should be marking 3 holes on each side for a total of 6 holes.
3. Drill the marked holes with a 9/32" drill bit. To do this it is recommended that you first center punch the marked holes so that the drill bit does not wander. You can choose to use some flat black paint to retouch the drilled holes. Allow to dry completely before continuing.
4. Using the six bolts and nylock nuts included in your kit, bolt the brackets onto the tube door gusset.
5. The included mirrors may have a 3-hole patterned bracket on the bottom. If they do, remove that bracket by removing the two nuts holding it on in the bottom of the mirror arm. Retain the two nuts and flat washer.
6. Install the mirrors onto the brackets by sliding the bottom of the mirror arm over the tube on the bracket. The threaded portion of the bottom stud will slide thru the hole and be accessible from the bottom of the brackets. Use the flat washer and nut you removed earlier to attach the mirror to the bracket. Tighten to a snug fit.
7. Sitting in your driver seat with the tube door closed; set the mirrors angle to the desired position and lock it into place by tightening the mirror to the bracket securely. Do not over tighten as you may damage your mirrors.
8. Finish the installation by hand adjusting the mirror lens to your preferred position.

Warrior also carries a full line of mesh covers, padding kits, and door limiting straps for your Tube Doors. Go to [www.warriorproducts.com](http://www.warriorproducts.com) to view additional accessories available for your tube doors.

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.