

Hardware included shown on right.

Tools required:

- 12mm socket
- 3/8" Nut driver
- 7/16" wrench
- 7/16" socket
- Drill
- Tape measure

-Painting your OFB board is not necessary nor is it recommended as there is no step tread to protect the painted stepping area. The board is made with UV protected TPO that will resist fading and cracking from the sun.



- 1) Remove factory bolts at 13 1/2", 39" and 59 1/2" on underside of body. Install FL225 at front location and FL226 at middle and rear locations with previously removed bolts.
- 2) Attach FL227 to FL226 with 1/4 nut and bolt.
- 3) Place board on brackets. Center board on vehicle. Attach with #14 X 3/4" self-drilling screws through slots in FL brackets into bottom of board.
- 4) **Apply the Owens logo.**
- 5) Repeat steps 1-4 for opposite side.

