

Warrior, Inc.

EXPLORER SAFARI RACK **INSTALLATION INSTRUCTIONS** **WAR 880**

Read all instructions before proceeding.

Your Ford Explorer must have the standard roof rack rails on both sides of the vehicle for this rack to mount properly. While the weight capacity of our cargo basket exceeds 400 lbs., with weight distributed evenly over the entire area of the rack, you should refer to your vehicle manual for the load capacity of the roof of your explorer, and be guided by those constraints.

1. Begin by removing the rear end caps from the rack rails on both sides of the roof. Then loosen and remove the locking tabs and the two cross rail assemblies by sliding them to the rear until they are clear of the rails.
2. Install the basket mounting brackets by first sliding one locking tab onto each rail, followed by three mounting brackets with the flanges pointed to the inside. Position the brackets approximately to support the front, middle, and rear of the basket.
3. Lift basket in place on top of the brackets and then adjust basket to center; forward to back and left to right. The brackets should be positioned directly underneath the front, middle, and rear basket floor cross members.
4. Insert the U-bolts provided, from the top, with the flat spacer on top of the cross member and the legs inserted through the holes in the mounting bracket. Tighten all nuts once you have confirmed that the basket is centered where you want it.
5. Reinstall the rear locking tabs on each side, and the rail end caps removed in step one (1) above. The locking tabs should be positioned tightly against the mounting brackets, both front and rear, and then tightened to secure the rack in place.
6. After a test drive, re-check tightness of all bolts and your done!

Enjoy your new Safari Rack by Warrior!

“Your Knight in Shining Armor!”