

Warrior, Inc.

TOW BAR - WAR 862 INSTALLATION INSTRUCTIONS

NOTE: Please read all instructions before starting installation of the TOW BAR.

Your Tow Bar should be installed by a professional installer or fabricator experienced at installing tow bars, and at wiring in lights on the tow vehicle. Points that need close attention:

1. Tow Bar should be as close to parallel with the ground as possible. You may need to alter the hitch on the tow vehicle to accomplish this. Drop hitches are available from Warrior Products in 2" increments.
2. Your coupler is designed to accept a 2" (two inch) ball only.
3. Bolt all attachments to the towed vehicle, welding is not recommended.
4. Fabricate a structure on the towed vehicle so that the Tow Bar is pulling on the frame only. If the Tow Bar is attached to a bumper, fabricate a support to the frame. (Similar to winch attachment)
5. Attach Tow Bar to the bumper attachment brackets. Position the attachment brackets where you want them installed on the front of your vehicle and mark holes for drilling. Drill the holes using a 1/2" drill bit. Be sure to wear safety glasses to protect your eyes. Remove the attachment brackets and install them using the 1/2" bolts, washers and nuts provided, then re-attach the Tow Bar to the brackets using the clevis pins provided.
6. Install two safety chains (they are not provided).

Note: Fulton Performance Products, Inc. couplers are used on Warrior Products, Inc. tow bars. Their "Coupler use, maintenance, installation and Service Information" sheet is included in the box along with our instructions. Please read and follow their advice.

You're done! Make sure that you read the warning label on the tow bar and adhere to the instructions. Re-check all bolts often, even during trips. Look for other quality Warrior Products on our web site, "warriorproducts.com".

"Your Knight in Shining Armor!"