

Universal Light Brackets

59001, 59003, 59004, 59005

Warrior Universal Light Brackets are designed to be installed onto any appropriately sized round tubing. This may include cargo racks, light bars, brush guards, or any other products using round tubing.

1. Be sure that any bare metal surfaces are repainted prior to installation, if needed, to prevent rust.
2. Place the brackets onto the tubing and assemble by placing the bottom portion of the “clam shell” on the backside of the tubing and inserting bolts through the pre-drilled holes. Place the lock washer and nut on the ends of the bolts, once inserted through the two halves of the bracket, and tighten loosely.
3. Position the brackets where desired on the tubing and tighten the bolts.

CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Nerf Bar Step Plate and be sure to look for other quality Warrior Products for your vehicle on our web site, “warriorproducts.com”.

Warrior, Inc. 11100 SW Industrial Way, Tualatin, Oregon 97062 Toll Free 888-220-6861

Universal Light Brackets

59001, 59003, 59004, 59005

Warrior Universal Light Brackets are designed to be installed onto any appropriately sized round tubing. This may include cargo racks, light bars, brush guards, or any other products using round tubing.

1. Be sure that any bare metal surfaces are repainted prior to installation, if needed, to prevent rust.
2. Place the brackets onto the tubing and assemble by placing the bottom portion of the “clam shell” on the backside of the tubing and inserting bolts through the pre-drilled holes. Place the lock washer and nut on the ends of the bolts, once inserted through the two halves of the bracket, and tighten loosely.
3. Position the brackets where desired on the tubing and tighten the bolts.

CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Nerf Bar Step Plate and be sure to look for other quality Warrior Products for your vehicle on our web site, “warriorproducts.com”.

Warrior, Inc. 11100 SW Industrial Way, Tualatin, Oregon 97062 Toll Free 888-220-6861

Universal Light Brackets

59001, 59003, 59004, 59005

Warrior Universal Light Brackets are designed to be installed onto any appropriately sized round tubing. This may include cargo racks, light bars, brush guards, or any other products using round tubing.

1. Be sure that any bare metal surfaces are repainted prior to installation, if needed, to prevent rust.
2. Place the brackets onto the tubing and assemble by placing the bottom portion of the “clam shell” on the backside of the tubing and inserting bolts through the pre-drilled holes. Place the lock washer and nut on the ends of the bolts, once inserted through the two halves of the bracket, and tighten loosely.
3. Position the brackets where desired on the tubing and tighten the bolts.

CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Nerf Bar Step Plate and be sure to look for other quality Warrior Products for your vehicle on our web site, “warriorproducts.com”.

Warrior, Inc. 11100 SW Industrial Way, Tualatin, Oregon 97062 Toll Free 888-220-6861