



HYDRAULIC BRAKE BOOSTER

COMPONENTS


BR



INSTRUMENT PANEL NO. 1 REGISTER ASSEMBLY




INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY



FRONT DOOR OPENING TRIM WEATHERSTRIP



HOOD LOCK CONTROL LEVER SUB-ASSEMBLY




COWL SIDE TRIM BOARD


FOOTREST CLIP

FRONT FLOOR FOOTREST

CLIP



FRONT DOOR SCUFF PLATE



$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

● Non-reusable part

* For use with SST

BR

