


# FRONT DRIVE SHAFT (for 4WD)

## COMPONENTS




**DS**

● FRONT DRIVE SHAFT HOLE SNAP RING



● FRONT DRIVE SHAFT DUST COVER

FRONT DRIVE INBOARD JOINT ASSEMBLY



● FRONT DRIVE INNER SHAFT SNAP RING

TRIPOD

● FRONT AXLE INBOARD JOINT BOOT NO. 2 CLAMP

● INBOARD JOINT BOOT

● FRONT AXLE INBOARD JOINT BOOT CLAMP

● FRONT AXLE OUTBOARD JOINT BOOT CLAMP


● OUTBOARD JOINT BOOT

● FRONT AXLE OUTBOARD JOINT BOOT NO. 2 CLAMP

Supply Part:



● FRONT AXLE OUTBOARD JOINT BOOT NO. 2 CLAMP



FRONT DRIVE OUTBOARD JOINT SHAFT ASSEMBLY

● Non-reusable part

DS