


STEERING COLUMN ASSEMBLY


COMPONENTS


SR



N*m (kgf*cm, ft*lbf) : Specified torque ● Non-reusable part

SR





N*m (kgf*cm, ft*lbf) : Specified torque ● Non-reusable part