




# AIR CONDITIONING UNIT

## COMPONENTS

AC




AC




$N^*m$  (kgf\*cm, ft\*lbf) : Specified torque




**for Automatic Transmission 2WD:**



**for Manual Transmission 4WD:**




**for Automatic Transmission 4WD:**




AC

AC




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

COMBINATION METER ASSEMBLY



7.0 (71, 62 in.\*lbf)

NO. 2 INSTRUMENT PANEL REGISTER ASSEMBLY




CLIP


NO. 1 INSTRUMENT PANEL REGISTER ASSEMBLY




INSTRUMENT CLUSTER FINISH PANEL




LOWER INSTRUMENT PANEL LH



INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY RH



LOWER INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY LH




GLOVE COMPARTMENT DOOR ASSEMBLY





HOOD LOCK CONTROL LEVER SUB-ASSEMBLY


**N\*m (kgf\*cm, ft.\*lbf)** : Specified torque



NO. 2 INSTRUMENT PANEL SPEAKER  
PANEL SUB-ASSEMBLY




2.5 (25, 22 in.\*lbf)




FRONT NO. 2 SPEAKER ASSEMBLY


2.5 (25, 22 in.\*lbf)



FRONT NO. 2 SPEAKER ASSEMBLY









**N\*m (kgf\*cm, ft\*lbf)** : Specified torque




AC

**N\*m (kgf\*cm, ft.\*lbf)** : Specified torque


AC









AC




LOWER DEFROSTER NOZZLE ASSEMBLY




HEATER TO REGISTER DUCT ASSEMBLY



AIR CONDITIONING UNIT ASSEMBLY



BLOWER UNIT ASSEMBLY



AC

**N\*m (kgf\*cm, ft.\*lbf)** : Specified torque

← Compressor Oil ND-8 or equivalent    ● Non-reusable part