


SYSTEM DIAGRAM



MI

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to help determine the causes of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

Power mirror control system

Symptom	Suspected area	See page
Mirror does not operate	ACC fuse	MI-2
	Outer mirror switch assembly	MI-14
	Outer rear view mirror assembly	MI-10
	Wire harness	-
Mirror operates abnormally	Outer mirror switch assembly	MI-14
	Outer rear view mirror assembly	MI-10
	Wire harness	-