


INSTALLATION

- 1. INSTALL FRONT EXHAUST PIPE ASSEMBLY
 - (a) Install a new gasket onto the exhaust manifold RH.
 - (b) Install the exhaust front pipe with the new 2 nuts. Torque: 54 N*m (554 kgf*cm, 40 ft.*lbf)








- (c) Install a new gasket onto the front exhaust pipe.
 - Using a wooden block and plastic-faced hammer, tap in a new gasket until it is flush with the front exhaust pipe end.
 NOTICE:
 - Make sure that the gasket is in the correct direction when installing.
 - Do not reuse the removed gasket.

2. INSTALL NO. 2 FRONT EXHAUST PIPE ASSEMBLY

- (a) Install a new gasket onto the exhaust manifold LH.
- (b) Install a new gasket onto the No. 2 front exhaust pipe.
- (c) Install the No. 2 front exhaust pipe with the 2 new nuts and 2 bolts and exhaust pipe support.
 Torque: Nut


54 N*m (550 kgf*cm, 40 ft.*lbf) Bolt 48 N*m (489 kgf*cm, 35 ft.*lbf)





EX-6

(d) Install the exhaust pipe stopper bracket with the 2 Torque: 19 N*m (193 kgf*cm, 14 ft.*lbf)



- 4. INSTALL TAIL EXHAUST PIPE ASSEMBLY
 - (a) Install a new gasket onto the center exhaust pipe.
 - (b) Install the tail exhaust pipe with the 2 bolts and exhaust pipe support.
 Torque: 48 N*m (489 kgf*cm, 35 ft.*lbf)
- 5. INSTALL HEATED OXYGEN SENSOR (See page EC-24)
- 6. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)

7. CHECK EXHAUST GAS LEAKAGE