



**PART#6071**  
**TOYOTA**  
**07-11 FJ CRUISER**

**REPLACEMENT**  
**FUEL DOOR**  
**INSTALLATION INSTRUCTIONS**

---

1. Remove the original door. (use a 1/4 inch drill bit and drill out the two rivets that attach the original door to the vehicle)
2. Remove the snap ring that holds the rubber fuel shroud in place.
3. Install one of the 8-32 jam nut on each stud on the back side of the fuel door, threading the nut about 3/4 down the stud.
4. While installing the fuel door with the studs into 1/4 inch holes, adjust the 8-32 jam nuts until the fuel door fits the best.
5. Move the rubber fuel door shroud to the right side and install the the plastic spacers, then the 8-32 jam nuts onto the studs.
6. Move the rubber fuel door shroud to the left and install the 1/4 inch U nut. Align the nut with the 1/4 inch hole on the fuel door.
7. Place the rubber fuel door shroud back to it's original position and reinstall the snap ring.
8. Install the 1/4 inch bolt through the fuel door and thread into the u nut and tighten.